



M901

DIY mini house kits -  
Dragon Gate Inn





M901 Instruction manual

# NOTICE OF ASSEMBLE

## Making tips


1. LED wiring indication:  
White=Positive; Grey=Negative.
2. Use a craft blade to carefully skim over the plastic to bare the copper wire.
3. For LED wiring extension, please refer to the below steps:



Twist the copper of both LED wire and extension wire together.




Do the same on the white wire.  
Remarks: Tie a knot at the end of the grey wire to differentiate the polarity.




Place the duly twist wire on the tapes provided.



Roll and wrap the wire.



Place another wire next to it.  
Remarks: DO NOT contact both copper wire to avoid short circuit.




Roll and wrap it together.

## Warnings


- The product is not suitable for children under 14 years old. The should be under custody of adults when playing with the product.
- There are small parts, please do not swallow them for avoiding dangerous accidents.

## Tips for assembling

1. Pictures shown on the package may be slightly different from the actual product.
2. Please use the provided tracing paper for cutting purpose to achieve the best outcome.
3. Product designs and specification may be subject to change without advance notice for purpose of making improvement.
4. Testing on LED function:



DO NOT contact the LED wire end direct to the battery cell.



Use the provide battery holder. Make sue the correct polarity.


## How to assemble the battery holder




1. Material and tools needed:  
- Battery holder, LED bulb, tape, screw driver and 2 piece AA size battery(not provided)



2. Use screw driver and take the lid off from the battery holder.




3. Insert the battery take notes on the polarity.



4. Connect the red wire to grey wire, Connect the black wire to white wire.



5. Wrap the exposed wire with the tapes.




6. Place the box lid and fastness with screw driver.

# Product information




Cut out the material G04 according to the template paper before making.

wall cabinet




Cut out the material G04 according to the template paper before making.

cabinet




teapot




A16-5 only needs to be pasted on one side, keep the other one for use.

abacus




display stand




Cut out the material G04 according to the template paper before making.

table




Cut out the material G04 according to the template paper before making.


snack cabinet



Cut out the material G02 and G03 according to the template paper before making.




Cut out the material G02 according to the template paper before making.




**table**




**Light**






Cut out the material G01 and G04 according to the template paper before making.




Cut out the material G04 according to the template paper before making.



Cut out the material A13 according to the template paper before making.




Cut out the material G04 according to the template paper before making.



Cut out the material G04 according to the template paper before making.







Cut out the material G04 according to the template paper before making.







Cut out the material A13 according to the template paper before making.


JOOL



fix one light on the roof as shown.









attach A02, A04 on A01 as above shown.

the wire of floor sign pass the hole as shown.


fix the wire according the red dotted line.



the wire of lights pass the hole of A03, fix A03 well as shown.



paste A16-56 on A03 as shown.




Note: cut the corners at right angles with a small knife.




Note: when installing D02, sand D02 if the hole is not big enough.

Cut out the material A15 according to the template paper before making.



cut out the material A15 according to the template paper, fold it according to the dotted line.


paste A12 to A09 as shown (note the position of A09 edge.)



### How to assemble the battery holder

**Statement: the lamp wires cannot be inserted into the output socket.**

- Can use 7 batteries
- Please notice the place of anode and cathode when pit in the batteries
- Rechargeable batteries are not blunt electricity
- Rechargeable batteries can only be charged under adult supervision
- Rechargeable batteries should be removed from the toy before charging
- Different types of batteries cannot mix;
- Do not mix new batteries in use with semi-used batteries.
- Run out of battery should be removed from the toy
- The power shall not be short circuit



Trim all the LED wiring to the same length.


Use a craft blade to carefully skim over the plastic to bare the copper wire. Twist the same color wire together.

Twist the following wire together:

- (I) BLACK wire from the battery box with the WHITE wire from LED bulb.
- (II) RED wire from the battery box with the GREY wire from LED bulb.

Roll and seal the duly twist copper with the white tape G25 provided. Place the battery box in the allocated space.

Cut out the material G04 according to the template paper before making.




G22:0.8cm


(note: to facilitate battery replacement, small doors should not be fixed to the panel.)



Installation of dust proof cover  
(For updated version, the parts need to be purchased separately)




scale 1:10  
H04 Transparent cover  
20\*16\*0.15cm  
1piece




scale 1:10  
H05 Transparent cover  
20\*18\*0.15cm  
2pieces



scale 1:10  
H06 Transparent cover  
18\*15.7\*0.15cm  
2pieces



1. Tear off kraft paper of each piece of transparent cover.



2. Paste H04, H05 and H06 together to complete the dust proof cover as shown.

## Photo of Dust proof cover





**Attention: Please keep the instruction for future enquires after installation.**